



- Jumper
 - ↑ ● 1006 MHz
 - — ● 1218 MHz
- Jumper
 - ↑ ● 65 MHz
 - — ● 85 MHz
 - ↓ ● 204 MHz
- Jumper
 - ↑ ● Return Path on
 - — ●